

Behavioral Healthcare Patient Room Access Door *Frequently Asked Questions*

1. Where is this product intended to be used?

Hospitals, mental health facilities, correctional facilities, extended care facilities, and nursing homes.

2. What is this product used for?

The product has been accepted by the New York Office of Mental Health as a solution for patients that may try to prevent care givers or authorized persons from entering the room.

3. Is the product fire rated?

Yes, up to 45 minutes. See Technical Manual for details.

4. Is hardware included?

CURRIES will supply the continuous hinge on the access door. All other hardware is not included and needs to be specified with the door.

5. Why are top caps required?

Patients and residents could try to hide contraband in the top channels of the entrance door.

6. Can more than one latch be used on the access door?

Yes, as long as the strike preparations will fit on the strike side of the opening for the access door.

7. When would more than one latch be used on the access door?

When specified or when there is a concern that the height of the door would require 2 locks for adequate security.

8. Can butt hinges be used on the access door?

The door is designed to use a continuous hinge on the access door. The full patient room door can have any type of architectural hinge to attach to the frame.

9. How is this door ordered?

Order the complete assembly as a 747 door on the order form. In special instructions write Behavioral Health – PRA. Select and fill out the special Behavioral Healthcare Patient Room Access Door elevation form. This can be found in the Partner area of the CURRIES website. The form will include all sizing and hardware information.